



newblinds.co.uk

Important!

The top and bottom limits of your blinds have been set in our factory.
Your blind will already be paired with the handset.
Please follow the guide below to get started with your blinds.

Getting Started

✓ Connect the blind to mains power

Each blind should be powered by its own 230vAC switched and fused power supply

✓ The blinds will now operate from the handset ordered

✓ Fine tune your blind's upper and lower

We pre-set the upper and lower limits of the blinds, but you may wish to fine tune them:

- 1) Power down all other blinds.
- 2) Use the handset to move the blind to the limit that needs to be adjusted.
- 3) Then, press and hold both the UP and the DOWN buttons until the blind shunts.
- 4) Then, use the UP and DOWN buttons to adjust the blind to the new limit position.
- 5) Once in the correct position, press and hold the MY button until the blind shunts.
- 6) The new upper or lower limit is saved

✓ Pairing the blind with an additional handset or channel

Blinds will already be paired with the handset purchased. To add your blind to an additional handset or channel:

1. Power down all other blinds.
2. Press the small button on the rear of the existing handset. The blind will shunt.
3. Select the channel that you wish to pair with on the additional handset.
4. Press the small button on the rear of the additional handset. The blind will shunt.
5. You will now be able to control the blind from the additional handset.

Notes on power and cabling:

Each motor is pre-fitted with 1.5m of 2-core power flex cable.

Each blind should be powered by its own 230vAC switched and fused power supply (e.g. a fused spur).

It's fine to trim the motor's power flex cable down when you are making final connections, but please be aware that the first 300mm of the power flex cable also incorporates the Somfy RTS (Radio) antenna, so this should not be trimmed!

FOR FURTHER SUPPORT

customer.services@newblinds.co.uk